

MGHA Scoreboard Directions

To set up:

- Push and hold “ON”
- Choose “scoreboard” #, hit enter
- “Use last setup?” No, enter
- Select sport: Hockey, 1 enter
- “Change game setup” Yes, Yes/No button top center, enter
- “Brightness” Enter
- “Period” 12:00 min., on keyboard push 1-2-0-0 then enter
- “Periods” 3, enter
- “Timeouts” 1 minute, Enter
- 1 allowed, enter
- Minor penalty 1:30, 1-3-0 enter
- Major penalty 5:00, 5-0-0 enter
- Autohorn: Yes, enter
- Last minute tenths, yes, enter
- Time of day, skip
- Set as default: Yes
- Hit “reset time” for period time to change to 12:00

Between Games

- Use “Intermission” button, enter 0-4-0-0 for 4 minute warm-up
- Start clock when teams take ice
- Hit “reset” for beginning of game.
- Make sure periods and scores are zeroed out
 - + period until reads zero
 - “-“ score until zero

Game Operation

- Use “Start/Stop” button bottom right corner to operate clock, green light comes on upper right when clock running
- Goals, +1 for Home or Guest, -1 to remove
- Periods, +1

Penalties

- Hit “penalty” button on the team it’s against, home or away
- Add player number then enter, example #5, type 0-5, enter
- Major or Minor, key which, then enter. Almost all penalties are minor. You’ll know if it’s a major, official will tell you. Penalty is automatic part of clock now. At end, open door for player.
- If opposite team scores goal during penalty, cancel penalty. Key “Delete” next to penalty, it will ask which one, choose, select “yes” top center, and hit enter.

Between Periods

- At each period end, give a 1 minute intermission:
- Key “Intermission”, top center, key in 0-1-0-0- enter, then run clock. Horn is automatic
- Hit “reset time” to return to period time

Period + 1

If officials ask to reset time:

Key “edit”

Enter new time, example 1:20 0-1-2-0 enter